

## **TRACKLINK Microphone to USB Interface**

### Connection and Setup Procedures

Thank you for purchasing the *TRACKLINK* Microphone to USB Interface by Hosa Technology. This interface enables you to connect your condenser or dynamic microphone directly to your computer. To get linked and start tracking, please follow these instructions carefully:

#### Connection Procedure

1. Plug the XLR connector into your microphone
2. Plug the USB connector into an available USB port on your PC
3. Follow the setup procedure for your computer below
4. Turn on 48 V phantom power (condenser microphone only)
5. Increase gain to taste (dynamic microphone only)

*Note: The gain control is intended to compensate for the lower output levels of dynamic microphones relative to condenser microphones. It should always be set as low as possible to minimize noise.*

#### Mac OS 10.3.9+ Setup Procedure

1. Go to Apple Menu>System Preferences and click Sound
2. Click the "Input" tab
3. Select "*TRACKLINK* Microphone to USB Interface"
4. Click the "Output" tab
5. Select your desired playback option
6. Close window

#### Windows XP Setup Procedure

1. Allow Windows to install the driver before proceeding
2. Go to Start>Control Panel
3. In Classic View, open Sounds and Audio Devices
4. Click the "Audio" tab
5. Under "Sound recording," select "*TRACKLINK* Microphone to USB Interface"
6. Under "Sound playback," select your desired playback option
7. Click the "Apply" button

#### Windows Vista Setup Procedure

1. Allow Windows to install the driver before proceeding
2. Go to Start>Control Panel
3. In Classic View, open Sound
4. Click the "Recording" tab
5. Select "*TRACKLINK* Microphone to USB Interface" and click the "Set Default" button
6. Click the "Playback" tab
7. Select your desired playback option and click the "Set Default" button

8. If you made any changes, click the “Apply” button
9. Click the “Okay” button

*Note: The TRACKLINK Microphone to USB Interface will appear as a playback option as well as a recording option. It cannot be used for playback, however.*

Your *TRACKLINK* Microphone to USB interface is now connected and you are ready to start tracking. Please consult your software's instruction manual for additional setup requirements. For technical support, please visit [www.hosatech.com](http://www.hosatech.com).

### Functions and Indicators

- Blue LED indicates proper connection when solid, recording when flashing
- Red LED indicates phantom power on when solid
- Switch controls phantom power for condenser microphones
- Thumb wheel controls input gain for dynamic microphones

### Warranty

All *TRACKLINK* products distributed by Hosa Technology, Inc. are warranted to be free of defects in materials and workmanship for one year. Please visit [www.hosatech.com](http://www.hosatech.com) for limitations.